



Instructions

opseyes is the industry's first artificial intelligence-powered wastewater testing solution that generates microscopy reports in under 10 minutes. All you need is a smartphone and a bracket (enclosed).



STEP ONE

As part of your normal routine, collect a wastewater sample.



STEP TWO

Then, add a few drops of mixed liquor or foam to a microscope slide.



STEP THREE

Secure your smartphone to a microscope using the provided mount.

- a. Attach the adapter on the eyepiece.
- b. Align the center of the camera with the half hole on the shield and tighten.



STEP FOUR

Once your smartphone is in place, take four different pictures of your sample.



STEP FIVE

Then go to opseyes.com to log in and submit your photos.

In minutes we will send you a report that either gives your wastewater the green light, or diagnoses issues along with remedial recommendations.

Once you've completed this process, please contact us with your feedback as well as any questions or concerns you have by emailing support@opseyes.com